







BRACKET COVER INSTALLATION

SKU# RB-BKC4, RB-BKC6, RB-BKC8

Raptor
Series

COMPONENTS	TOOLS REQUIRED	INSTALLATION NOTES
 <p>Qty: 4, 6 or 8 Bracket Cover A</p> <p>Qty: 4, 6 or 8 Bracket Cover B</p>	<p>SCISSORS</p> 	<p>NOTE: Bracket Cover quantity will vary depending on the SKU you purchased. Each Bracket Cover is 2 pieces (Bracket Cover A & B)</p> <p>NOTE: If you have already installed your steps you will first need to remove the steps to install the Bracket Covers.</p> <p>NOTE: Minor trimming may be required for desired look and fit.</p> <p>NOTE: Bracket Covers will not cover up additional supporting braces on some applications. They are designed to cover the main bracket.</p>
<p>1. Place (1) Bracket Cover A onto the installed bracket to identify if there is any trimming needed.</p>  <p>INSTALLED BRACKET</p> <p>BRACKET COVER A</p>	<p>2. If trimming is necessary, carefully trim the Bracket Cover using scissors or a knife until you reach your desired look and fit (2a). Once this is complete, place the Bracket Cover A onto the installed bracket (2b).</p>  <p>2a</p> <p>2b</p>	
<p>3. Place (1) Bracket Cover B over the end of Bracket Cover A (3a). Next, align the slots in the Bracket Covers with the holes in your bracket (3b). Repeat steps for all of the remaining brackets for the Driver & Passenger side.</p>  <p>BRACKET COVER A</p> <p>3a</p> <p>3b</p> <p>SLOTS ALIGNED</p> <p>BRACKET COVER B</p>	<p>4. After the Bracket Covers are in place, fasten the Driver Side & Passenger Side Running Boards to the Brackets by using the hardware specified in your installation guide.</p>  <p>NOTE: Sample board install shown. Board installation may vary.</p> <p>UNDERSIDE OF RUNNING BOARD</p> <p>M8 FLAT WASHER</p> <p>M8 LOCK WASHER</p> <p>M8 HEX HEAD NUT</p> <p>INSTALLED BRACKET</p>	